



U.S. Patent No. 6,047,490 • Patents Pending

Fire Cartridges with your Cap & Ball revolver

Installing Ejector Systems

1851 Colt Ejector

Remove the loading lever screw and loading lever.

Back the barrel wedge out and slide the ejector assembly into the loading lever slot.

Re-install the screw.

Minor amounts of filing or shimming may be required to get a rigid installation. Cut narrow strips of a business card for shims.

1860/61 Colt Ejector

Remove the loading lever screw and loading lever.

Back the barrel wedge out and slide the ejector assembly into the loading lever slot.

Insert ram plug with the angled end out; line up angled end of plug with the ejector bracket. Tighten set screw.

Some filing for a finer fit may be required.

1858 Remington Ejector

Remove the loading lever screw

Remove the Loading Lever and Cylinder Pin.

Install the cylinder pin/ejector rod assembly and loading lever.